


JSJ SERIES PARTS & ASSEMBLIES

5/8" THRU 2" SIZES

The schematic drawing below shows the breakdown of parts for our JSJ series meters. For ordering information of parts, continue to next page and view part assemblies.



MODEL	METER/PIPE SIZE	MODEL	METER/PIPE SIZE
JSJ062	5/8" X 1/2"	JSJ100	1"
JSJ0621	5/8" X 3/4"	JSJ1001	1" X 1 1/4"
JSJ075	3/4" X 3/4"	JSJ150	1 1/2"
JSJ0751	3/4" X 1"	JSJ200	2"

JSJ SERIES PARTS & ASSEMBLIES

5/8" THRU 2" SIZES

WHEN ORDERING, PLEASE SPECIFY: 1. QUANTITY 2. METER SIZE 3. ASSY NUMBER & DESCRIPTION

(WHEN ORDERING PARTS, AN UPPER SHELL CASTING MARK AND/OR SERIAL NUMBER IS REQUIRED).

ASSEMBLY NO.	ASSEMBLY DESCRIPTION	PARTS ASSEMBLY LIST
A308 (MODEL NO.) - ____ GPC Example: A308JSJ062 - 10 GPC	PULSEHEAD ASSEMBLY	ELECTRIC CONTACT REGISTER HEAD SEAL GASKET
A13 (MODEL NUMBER)	UPPER MAIN CASE ASSEMBLY	UPPER MAIN CASE HEAD SEAL GASKET MAIN CASE GASKET
A14 (MODEL NUMBER)	LOWER MAIN CASE ASSEMBLY	LOWER MAIN CASE HEAD SEAL GASKET MAIN CASE GASKET CHAMBER SEAL GASKET CONNECTION GASKETS
A33 (MODEL NUMBER)	CHAMBER ASSEMBLY	CHAMBER TOP LOWER MAGNET DRIVE PISTON SCREEN (& SCREW) CONTROL ROLLER DIVISION PLATE CHAMBER BOTTOM HEAD SEAL GASKET MAIN CASE GASKET CHAMBER SEAL GASKET
A17 (MODEL NUMBER)	LOWER DRIVE ASSEMBLY	UNIVERSAL DRIVE ASSEMBLY HEAD SEAL GASKET MAIN CASE GASKET CHAMBER SEAL GASKET CONNECTION GASKETS
A35 (MODEL NUMBER)	SEAL & SCREEN KIT	HEAD SEAL GASKET MAIN CASE GASKET CHAMBER SEAL GASKET CONNECTION GASKETS SCREEN (& SCREW)
A38 (MODEL NUMBER)	CONNECTION KIT (INCLUDES TWO CONNECTIONS)	TAILPIECE NUT GASKET BUSHING (1 1/2" & 2" SIZES)

MINIMUM BILLING: \$50.00